



## CLEANING THE DENSIFIER



### WARNING!

The operations described in this technical data sheet and those contained in the relative video tutorials which can be captured via QR CODE must only be performed by qualified technicians and only after having read the safety information contained in the specific sections of the use and maintenance manual.

*When in doubt, do not interpret! Instead directly contact the Colombini Srl technical assistance service at +39 011 8211407 [service@colombini.srl](mailto:service@colombini.srl)*



To remove/reinstall the extractor, the following are required:

- a) Allen wrenches - 2.5 mm, 5 mm and 6 mm
- b) wrench - 10 mm

## REMOVING AND CLEANING THE DENSIFIER



### WARNING!

Disconnect the machine electric power supply.



### WARNING!

Use cut-resistant gloves.



- Using a 10 mm wrench, unscrew and remove the four bolts securing the densifier cover.
- Remove the cover.
- Use a 6 mm Allen wrench to unscrew the eight screws that secure the internal densifier cover.
- Remove the internal densifier cover.
- Grasp and gently remove the gridded cylinder inserted inside the densifier.
- Use a vacuum to clean the front internal area of the densifier.



### CAUTION!

Set a suitable tray under the densifier unit to collect any product.



- Use a 2.5 mm Allen wrench to unscrew the four screws securing the upper cover to access the densifier.
- Lift the upper cover to be able to access the internal central compartment of the densifier.
- Use a vacuum to clean the internal central area of the densifier.

- Using a 5 mm Allen wrench, unscrew and remove the screw locking the sealing ring and remove it from its seat.
- Turn the densifier unit fully outwards.
- Use a vacuum to clean the upper cone of the densifier.

## REINSTALLING THE DENSIFIER



- Turn the densifier unit fully inwards.
- Position the densifier unit sealing ring in its seat and lock it in place by tightening the specific screw.
- Close the upper cover of the internal central compartment of the densifier.
- Tighten the four Allen screws of the cover.
- Insert the grilled cylinder in its seat in the front part of the densifier.
- Insert and tighten the densifier internal cover with the 8 6 mm Allen screws.
- Lock the densifier external cover with its screws.

The texts, trademarks, and images contained in this sheet and in the relative videos that can be captured via QR CODE are protected by copyright laws and are the property of Colombini Srl; the User must not republish, modify, rework, or commercially exploit these contents in any way.

The instructions given in this sheet represent general good practice. COLOMBINI SRL is not responsible for the conditions in which its systems are installed and thus cannot be held liable for the specific variations required to adapt them to the industrial context; in this regard, see the safety, prevention and protection indications in force at the User's site.

The User acknowledges and agrees that COLOMBINI Srl, and its suppliers, will not be held liable in any way for any sort of damage of any nature whatsoever, even as related to lost profits, resulting from the User's public use of the video tutorials and related content.

It is understood that this technical data sheet and the contents of the video tutorials available via QR CODE are strictly indicative. COLOMBINI Srl provides this technical documentation for the sole purpose of facilitating the maintenance operations described. In particular, neither COLOMBINI Srl nor its suppliers are responsible for any infringement of the law or of third party rights by the User derived from implementing the contents of the above-mentioned video tutorials.